

General

Our products are designed to comply with the recommended codes of practice for lighting and to be installed and serviced by competent persons in accordance with the relevant regulations.

Preparation For Use

Ensure that the smart phone is connected to the same Wi-Fi network that you would like to attach the device.

Ensure that you have a mobile device running iOS 8 or higher or Android 4.1x or higher and a 2.4GHzWi-Fi connection.



Download the ClickSmart+ App on your mobile device from the App Store or Google Play.


Sign in or Register following the instructions on the ClickSmart+ App.


Contents

- Indoor Camera
- Mounting Pack
- Micro USB Power Cable
- USB Power Adapter
- User Manual

Installation

Connect the supplied power adapter to the camera and apply power, the camera will operate after 30secs.






Reset Button



APP Pairing


- 1. Power up the device VIA the 5V Micro USB Cable
- 2. After 30 Seconds, a double chime will be heard every 30 seconds.

The ClickSmart+ app will guide you through: Entering the Wi-Fi Network and Password. Using the Camera to scan a QR code. Connecting the Device.



Resetting the Device

If the camera needs to be reset, connected to a new Wi-Fi network, or if it needs to be paired with a new master account, remove the device from the app, prior to resetting the device.



- 1. Using the reset key, long press the reset button until 3 chimes are heard.
- 2. The device should now be reset, after 30 seconds, there should be a double chime heard.

Guidance

>Unit requires a minimum of 2 Mbps (upload/download) >This unit only operates on 2.4GHz

>If the signal strength of your Wi-Fi router is weak: Change router/camera relative position to receive better signal, Use Wi-Fi repeater/extender to maximize the range of your Wi-Fi router.

>If the device is installed on a new network the unit will require resetting

>If the camera needs to be added to a new account, unbind the device from the first account prior to resetting the device.

For more product information please visit the ESP website



Telephone : 01527 51 51 50 Fax: 01527 51 51 43 Email : info@espuk.com Web : www.espuk.com E&OE - Errors and omissions excepted.G21