

## General

Our products are designed to comply with the recommended codes of practice for lighting and to be installed and serviced by competent persons in accordance with the relevant regulations.

## Contents

- Smart Doorbell
- 2 x Lithium 18650 Batteries
- Mounting Pack
- Micro USB Cable
- Micro SD Card
- RF Chime

## Preparation For Use


Ensure that the smart phone is connected to the same Wi-Fi network that you would like to attach the device.

Ensure that you have a mobile device running iOS 8 or higher or Android 4.1x or higher and a 2.4GHz Wi-Fi connection.




Download the ClickSmart+ App on your mobile device from the App Store or Google Play.

Sign in or Register following the instructions on the ClickSmart+ App.



## Installation

- Open up the rear cover to insert batteries & Micro SD Card
- Mount the mounting backplate onto the wall, using the 4 holes to mount to the desired surface.
- Push the Doorbell down onto the backplate, and secure with fixing screw.



### Indoor Chime unit


- The chime unit comes pre-paired with the video doorbell. If it doesn't sound when it should refer to the below:
- Press the "ring" button, to choose your desired ringtone. The indoor chime offers 36 different ringtones. Each press changes the current ringtone.
- Press the "volume" button for 5 seconds, till the music changes.
- Press the doorbell button to match the indoor chime. You can now press the call button of the doorbell and listen for the chime.
- To change the ringtone, please refer to the above pairing instructions.
- To change the volume, press the "volume" button once, to trigger it. There are 4 different volume levels to choose, from Low to High.



## APP Pairing

1. Power up the device VIA the 5V Micro USB Cable, and fully charge
2. Once powered up. The LED on the front should be flashing blue, and it should say “the camera is now ready to being pairing”.


The ClickSmart+ app will guide you through:  
 Entering the Wi-Fi Network and Password.  
 Using the Camera to scan a QR code.  
 Connecting the Device.



## Resetting the Device

If the camera needs to be reset, connected to a new Wi-Fi network, or if it needs to be paired with a new master account, remove the device from the app, prior to resetting the device.

1. Using the reset key, long press the reset button until “system reset” is heard.
2. The device should now be reset, after 30 seconds, the unit should start to flash blue, and say “the system is now ready to begin pairing”.



## Guidance

- >8-12hrs charge time required for full battery capacity
- >Unit requires a minimum of 2 Mbps (upload/download)
- >This unit only operates on 2.4GHz
- >If the signal strength of your Wi-Fi router is weak: Change router/camera relative position to receive better signal, Use Wi-Fi repeater/extender to maximize the range of your Wi-Fi router.
- >If the device is installed on a new network the unit will require resetting
- >If the camera needs to be added to a new account, unbind the device from the first account prior to resetting the device.

For more product information please visit the ESP website

